

**PIX LENGTH FINDER  
STANDARDS:**



The PIX Length Finder is used for checking the length where size on the belt is not clearly visible. It can also be used to confirm the type of belt section of the belt. In both cases the results are not exact but very good indicators.

PIX has two types of Length finders

- Conventional
- Poly-V

The maximum belt length which can be measured with these length finders is 120 inches. (3048 mm)

**Belt length measurement procedure**

1. Place the belt on the upper half of the pulley which is fixed.
2. Slide down the lower half of pulley with the belt along the scale till the belt gets sufficiently stretched.
3. The marker at the lower position of the bottom half will show the reading in mm / inches. Note down the reading and compare this value with the belt size mentioned on the belt.